### LEUPOLD CONTROL APP **Operating Instructions**

### TABLE OF CONTENTS Introduction

Menu Navigation **Pinning** 

Remote Setup Battery Management

Legal

Software Updates

INTRODUCTION

Long Range Mode

### the field as you customize modes and settings, capture accurate ranges, and precisely drop GPS waypoints—all with just a few quick taps.

product manual. Product manuals can also be found at Leupold.com. MENU NAVIGATION 10:35 2:31 SETTINGS SUPPORT RANGE RESULTS TRIG LOAD: 15 -0-H

**Battery Level** 


RX5000 S/N: PRAIJ010.


The Leupold Control app transforms your mobile device into a powerful


command center for select Leupold products. With it, you'll dominate

Note: To connect your device, see the Bluetooth Pairing section of your

### --- O LOS: ---- y MAP: onX Hunt AUTO MAP








Downloads


Support

RX5000 S/N: PRALJ010. **Battery Level** About Pinning **Product Settings** 


Compliance COMPASS







onX Hunt **Auto Map Results** My Location



0 47 3

During manufacturing, the compass undergoes calibration using our

through the Leupold Control App on every outing. To calibrate, access

proprietary process, providing a high level of accuracy (<1° RMS).

However, to maintain this accuracy, you must initiate calibration

instructions. Once calibration is complete, the status bar will show 100% and default to the Range Results page, signifying that the rangefinder is DROPPING WAYPOINTS

13° 🕣

0

will automatically appear on the screen. If Auto Map Results is off, you

can choose to manually send the pin or pin again. To exit the pinning

onX Hunt

**PIN RESULTS** 

1691

AUTO MAP

SEND PIN

PIN NEXT


REMOTE FIRE


4

MED MED

·1°Z

3





activate the rangefinder by pressing and holding down the power button, using the Remote Fire button in the Leupold Control App will further REMOTE SETUP al 🗢 🗔 10:35 10:35 SETTINGS Back RX5000 SETTINGS

Output

**Function** 

**Display Brightness** 

**Bluetooth Timeout** 

Measurement

**Last Target** 

Reticle

Load

CDS

15


YARDS -

30 sec-

PLUS POINT

SOFTWARE UPDATES RANGE RESULTS

## **BEGIN UPDATE** DISMISS



To install the new software, simply follow the on-screen instructions. If the unit's battery dies before an update is complete, replace the battery, and the Leupold Control App will prompt you to resume the download. Product compliance information is located in the About section of the

Please see this section for any compliance information not found on the

product or in the product manual. Artwork# 184736

# solutions like on X Hunt, Google Maps, and Apple Maps. represented in the drop-down menu on the pinning settings screen.

SETTINGS

Manually calibrate your compass for optimum performance in the field. CALIBRATE  $\oplus$ 4 3

Done onX Hunt Apple

12:30

PINNING

AVERAGE BEST

**✓** Back

**CALIBRATION** 

the Settings page, click the Calibrate button, and follow the on-screen ready for pinning. **AWAITING RESULTS** O MED

process, simply use the rangefinder as usual. To pin a waypoint in onX Hunt, a membership is required, either Premium or Elite. To add a second waypoint, repeat the pinning process. Pins created through the Leupold Control App are marked with the Leupold logo. is not liable for inaccuracies. LONG RANGE MODE calculate distances out to almost three miles.

included tripod saddle.

RANGE RESULTS

AUTO MAP

PIN NEXT

REMOTE FIRE

4

3

RX5000 S/N: PRAIJ010.

90%

3

· MED

5,000 yards.

MAP: onX Hunt

 $\oplus$ 

Once the device is locked into the saddle, you can range a target by pressing Remote Fire on the Range Results page. Although you can enhance stability.

**Battery Level** 

About

Pinning

**Product Settings** 

COMPASS

Quality: GOOD Manually calibrate your compass for optimum performance in the field.

CALIBRATE

Compliance

 $\oplus$ 

To remotely view and adjust your rangefinder's settings, pair your rangefinder with the Leupold Control App, then navigate to the Settings corresponding value. rangefinder's display.

page (the wrench icon at the bottom of the screen) and access the Product Settings submenu. This menu will only appear when your rangefinder is connected to the app. To modify a setting, simply tap its **BATTERY MANAGEMENT** When the rangefinder is not in use, we recommend performing a hard close on the app to terminate the Bluetooth connection and save battery life. You can monitor the battery status in the app or directly through the