

RX[®]-5000 TBR/W Quick Reference Card

Basic Operations

Press POWER to activate the rangefinder.

Press and release POWER for a single distance reading.

Press and hold POWER to scan, continuously updating distance readings (recommended).

Menu Navigation

Press and hold BUTTON 1 to enter the menu.

Press and release BUTTON 1 repeatedly to advance through the menu.

Press POWER to toggle functions on or off.


Long Range

Achieve greater ranging distances in Long Range mode, allowing you to range up to 5,000 yards on trees. The rangefinder must be kept completely still to use Long Range Mode effectively.

Pinning Feature

Mark your targets on a variety of digital mapping systems connected to the Leupold Control App.

Display at a Glance



1. Output settings
2. Reticles
3. Unit
4. Incline/Decline Angle
5. Battery
6. Distance
7. Windage/Elevation/Hold
8. Last Target

True Ballistic Range[®]

Choose between CDS, MIL, and MOA. CDS is the default setting for TBR and displays equivalent horizontal distances. MIL and MOA display holdover values in Milliradians and Minute of Angle to help you place your shots.

To use CDS, MIL, or MOA, you'll need to select the load group that matches your bullet weight and muzzle velocity.

Use the **Leupold Control App** to quickly match your ammo and rifle to the correct ballistics group. Or go to the RX-5000 TBR/W product page at leupold.com and select "Product Downloads" for a list of common load groups.

TBR/W LOAD GROUP SELECTION TABLE: FOR BEST FIT UP TO 600 YARDS

Load Group	Bullet Path Height @ 600 Yds.	10 MPH Crosswind Deflection @ 600 Yds	Sight-in Range
1	-42 to -48 inches*	10 to 28 inches	200 Yards
2	-48 to -54 inches	10 to 28 inches	200 Yards
3	-48 to -54 inches	28 to 46 inches	200 Yards
4	-54 to -60 inches	10 to 28 inches	200 Yards
5	-54 to -60 inches	28 to 46 inches	200 Yards
6	-60 to -66 inches	10 to 28 inches	200 Yards
7	-60 to -66 inches	28 to 46 inches	200 Yards
8	-66 to -72 inches	10 to 28 inches	200 Yards
9	-66 to -72 inches	28 to 46 inches	200 Yards
10	-72 to -78 inches	10 to 28 inches	200 Yards
11	-72 to -78 inches	28 to 46 inches	200 Yards
12	-78 to -84 inches	10 to 28 inches	200 Yards
13	-78 to -84 inches	28 to 46 inches	200 Yards
14	-84 to -90 inches	10 to 28 inches	200 Yards
15	-84 to -90 inches	28 to 46 inches	200 Yards
16	-90 to -96 inches**	28 to 46 inches	200 Yards
17	-30 to -36 inches**	10 to 28 inches	300 Yards
18	-36 to -42 inches	10 to 28 inches	300 Yards
19	-42 to -48 inches	10 to 28 inches	300 Yards
20	-48 to -54 inches	10 to 28 inches	300 Yards
21	-48 to -54 inches	28 to 46 inches	300 Yards
22	-54 to -60 inches	10 to 28 inches	300 Yards
23	-54 to -60 inches	28 to 46 inches	300 Yards
24	-60 to -66 inches**	10 to 28 inches	300 Yards
25	-60 to -66 inches**	28 to 46 inches	300 Yards

* If your bullet drop is less than -42 inches at 600 yards with a 200-yard sight-in, consider sighting in at 300 yards and selecting load group 17 or 18. Alternately, you can use group 1 with a 200-yard sight-in, but the results will be less accurate.

** If your bullet drop at 600 yards is greater than -96 inches with a 200-yard sight-in or less than -30 or greater than -66 inches with a 300-yard sight-in, the results will be less accurate.